



the shell of both of plugs should be inter-connected using the shield, and connected to GND in both plugs. SHIELD LED is on when both shells are connected to GND (but might not be inter-connected), or they are inter-connected and at least one end is connected the GND.